




VAP11G Modified external antenna Guide



1. Remove C5 to weld to C6 position

2. Weld ANT Signal and ANT GD

ANT Signal

ANT

